

STILO-LED LINEAR STRIP LIGHT










Features & Benefits

- 1. Daisy connection with very convenient replacement in 1minute.
- 2. 0-10v dimming, universal voltage: 120-277v
- 3. Available with suspending installation and surface-mounted installation.
- 4. Wide application for: school, hospital, super market, office and warehouse.
- 5. 2ft, 4ft and 8ft dimensions for variety choices.
- 6. 5-year warranty.

Product Dimension



Specification

Part No.	Power	Input Voltage	Luminous Flux	Luminous Efficacy	ССТ	Viewing Angle	Ra	PF	Warranty	Emergency Power	Emergency Time
STILO-ST4-4FT40W- TCP	25W,30W 40W	AC120-277V	3250LM 3900LM 6500LM	130lm/W	3500K 4000K 5000K	120°	>80	>0.9	5 Years	8W	90 Minutes
STILO-ST4-4FT-40W- TCP-MS	25W,30W 40W		3250LM 3900LM 6500LM								
STILO-ST4-4FT40W- TCP-EM	25W,30W 40W		3250LM 3900LM 6500LM								
STILO-ST4-4FT40W- TCP-MS-EM	25W,30W 40W	,	3250LM 3900LM 6500LM								
STILO-ST4-8FT64W- TCP	64W	AC120-277V	8320LM	130lm/W	3500K 4000K 5000K	(120°	>80	80 >0.9	5 Years	8W	90 Minutes
STILO-ST4-8FT64W- TCP-EM	64W		8320LM								

The following multiple functions can be achieved according to customers' requests


- 1.Remove or turn off the emergency battery when testing the luminous efficacy.
- 2. Available with external or built-in microwave motion sensor
- 3. Emergency: the power is 8W, it can still work in 1.5hrs while emergency situation.
- 4. Remove or turn off the emergency battery when testing the luminous efficacy.








Testing Report






Applications








CCT&Wattage selectable





Installation manual

A.Surface-mounted installation Parts List



Installation instructions













2. Swing open fixture by pushing in/squeezing both buttons located on opposite ends.




3.Run the fixture's power wires through the center hole.
of the round J-box adapter. Slide and secure the round J-Box
adapter on the center slots located on the back of the
fixture.
Note: J-Box adapter is used to cover the Junction Box










6. Press upward the cover and lock it with springs tightly which located into the fixture.



7. The installation is completed and energize the luminaire to verify operation.












B. Suspending installation Parts List


Suspending installation -4FT(included)							
		Parts: (2) Safety Rope (2) Anchors (2) Screw					
Suspending installation -8FT (inlcuded)							
		Parts: (4) Safety rope (4) Anchors (4) Screw					


Installation intructions




























C.Continuous Row Mounting

4G LED Strip Light Linkable QTY

0:	\\/ atta	120V		277	7V	Suggested	
Size	Watts	Current	QTY	Current	QTY	Linkable QTY	
4FT	25W,30W 40W	0.46	10	0.2	24	≤10 PCS	
8FT	64W	0.65	7	0.28	17	< 8 PCS	

4G LED Strip Light Linkable QTY

C:	10/0440	120V		27	7V	Suggested	
Size	Watts	Current	QTY	Current	QTY	Linkable QTY	
4FT	25W,30W, 40W	0.46	10	0.16	30	≤10 PCS	
8FT	64W	0.65	7	0.23	21	<8 PCS	



1.Surface-mounting continuous row mounting(daisy connection) **Parts List**

Continuous Row Mounting-4FT(included)

Parts:

- (1) Connection Bracket
- (1) Harness set
- (5) Wire Nuts
- (2) Anchors
- (2) Screws
- (2) Self-adhesive Cable Ties


Continuous Row Mounting-8FT(included)





Parts:


- (1) Connection Bracket
- (1) Harness set
- (5) Wire Nuts
- (4) Anchors
- (4) Screws
- (2) Self-adhesive Cable Ties


Installation instructions





























9.Take the black/white/green wire harness and connect to the existing wire connectors on the input wires of the driver respectively. When using the dimming function, take the purple and pink wire harness and make connection to driver. Please make wiring connection using the wiring diagram in Step 8.




10. The same type of electronic wires are inserted into the same wire nut and combined into a parallel circuit.




11. Tighten the wires in the wire nut as the photo shows below.



12. Once wiring is completed, take wire harness and run it thought the knockouts of the connecting fixture. Use self-adhesive cable ties to eliminate any cable tangles and clutter.



13. Secure the LED Cover to the housing by pressing upward and lock it into the fixture. Energize the luminaire to verify operation









2. Suspending continuous row mounting(daisy connection) Parts List

Continuous Row Mounting-4FT(included)

Parts:

- (1) Connection Bracket
- (1) Harness set
- (5) Wire Nuts
- (2) Anchors
- (10) Screws(2) Self-adhesive Cable Ties
- (2) Safety Rope


Continuous Row Mounting-8FT(included)





Parts


- (1) Connection Bracket
- (1) Harness set
- (5) Wire Nuts
- (2) Anchors
- (12) Screws
- (4) Self-adhesive Cable Ties
- (2) Safety Rope


Installation instructions

































12.Take the black/white/green wire harness and connect to the existing wire connectors on the input wires of the driver respectively.


When using the dimming function, take the purple and pink wire harness and make connection to driver. Please make wiring connection using the wiring diagram in Step 11.









14. The same type of electronic














Installation of Emergency Power Supply

STEP 1: Press the Spring buttons and remove fixture cover/diffuser.




STEP 4: Image of the Emergency power supply installed.




Optional Emergency power supply


STEP 2: Use a flat screwdriver to remove knockouts on the bottom of fixture housing.




STEP 5: Remove plastic nut from the Test/Indicator button.




STEP 3: Align the Emergency power supply with the studs on the bottom housing and secure with supplied nuts.



STEP 6: Install the Test/Indicator button through the knockout on the side of the fixture housing and secure with plastic nut.






STEP 7: Connect wire leads from Test/Indicator button to wire leads from the Emergency power supply.

Wiring Diagrams

In order to avoid interference between the microwave sensors during operation, the installation distance between the lamps should not be less than one meter.



LED panel







Note

- 1. The installation and maintenance must be completed by electricians or professionals.
- 2. Please cut off the power before installation and maintenance.
- 3. The thermally insulating material is not allowed to cover the fixture.
- 4. Please keep away from the corrosive substance, and keep the fixture dry and clean.
- 5. Working temperature: -4°F~113°F, storage temperature: -22°F~140°F.

Important ===

Read this instruction carefully before installation. Keep it for further reference. Make electrical and grounded connections in accordance with the national electrical code and any applicable code. Always turn off the power supply before installation.

This product must be installed in accordance with the applicable installation code by a qualified electrician who is familiar with the construction and operation of the product and the hazards involved.

WARNING:

Risk of fire or electric shock. Fixture installation requires knowledge of luminaires electrical systems. If not qualified, DO NOT attempt installation. Contact a qualified electrician.

Always turn off the power supply before installation.

Risk of fire or electric shock. Suitable for non-insulated surface and frame. DO NOT cover fixture with insulation liner or similar material.

DO NOT install fixture on unstable, loose or easily breakable surface.

DO NOT exert force on the surface of the fixture.

Packing /weight



Packing I

Packing II

Size	Inner box (L*W*H)	Outer box (L*W*H)	Qty/CTN (pcs)	N.W./pcs (lbs/kg)	G.W./CTN (lbs/kg)	Remark
4ft	48.8"*3.54"*4.13" 1240*90*105mm	49.6"*11.8"*9.84" 1260*300*250mm	6	3.75/1.7	26.5/12.1	NACIO - A Company
8ft	96.8"*3.54"*4.13" 2458*90*105mm	97.6"*8.07"*9.84" 2478*205*250mm	4	7.2/3.28	32.5/14.8	Without inner box



Size	Outer box (L*W*H)	Qty/CTN (pcs)	N.W./pcs (lbs/kg)	G.W./CTN (lbs/kg)	Remark
4ft	49.4"*10.8"*8.27" 1255*275*210mm	6	3.75/1.7	29.1/13.1	NACIL TO A SERVICE OF THE SERVICE OF
8ft	97.4"*7.48"*8.27" 2475*190*210mm	4	7.2/3.28	35.9/16.2	With inner box





